

Model	BA300
Weight Capacity	400 lbs.
Maximum Speed¹	Up to 14 mph
Ground Clearance³	3.5" at center of frame, 1.37" at anti-tip, 6.18" at highest point
Turning Radius³	60"
Overall Length³	59"
Overall Width³	27.12"
Seat-to-Ground Height³	28"
Seat-to-Deck Height³	19"
Front Tires³	3" x 16" tubeless pneumatic
Rear Tires³	3" x 16" tubeless pneumatic
Suspension	Front and rear
Range Per Charge^{1,2}	Up to 19 miles at 400 lbs. at full speed Up to 31 miles at 220 lbs. at low speed
Total Weight⁵	Without batteries: 212.8 lbs. With batteries: 318.8 lbs.
Standard Seating³	Type: Limited reclining high back with sliders Weight: 45.6 lbs. Material: Black vinyl Dimensions: Width: 20", Depth: 18"
Drive System	Rear-wheel drive sealed transaxle with 24-volt DC motor
Dual Braking System	Regenerative and electromechanical
Battery Requirements^{4,6}	Size: (2) 75 AH Weight: 53 lbs each
Battery Charger	8 amp, off-board
Warranty	Frame: lifetime limited Drivetrain: 2-year limited Electronics: 2-year limited Battery: 6-months

**Non-Medical Device

This product is not a medical device and is not intended to assist, treat, diagnose, or alleviate any medical condition or disability.

- 1 Varies with user weight, terrain type, battery amp-hour (AH), battery charge, battery condition, and tire condition. This specification can be subject to a variance of (+ or -) 10%.
- 2 Tested in accordance with ANSI/RESNA, MC Vol2, Section 4 & ISO 7176-4 standards. Results derived from theoretical calculations based on battery specifications and drive system performance. Test conducted at maximum weight capacity.
- 3 Due to manufacturing tolerances and continual product improvement, this specification can be subject to a variance of (+ or -) 3%.
- 4 Battery weight may vary based on battery manufacturer.
- 5 Includes standard seat weight.
- 6 AGM or gel cell type required.



NOTE: All specifications subject to change without notice. The information contained herein is correct at the time of publication; we reserve the right to alter specifications without prior notice. Speed and range vary with user weight, terrain type, battery charge, battery condition and tire pressure. Due to manufacturing tolerances and continual product improvement, length, width, turning radius and ground clearance can be subject to variance of + or - 3%. Special order seats or non-standard dimensions will not be fold-flat and depth-adjustable.

0004390-092822

BAJA RAPTOR 2

Non-Medical Device**

**GET OUTDOORS
AND ENJOY LIFE**

BAJA MOBILITY



PERSONALIZE YOUR BAJA™ RAPTOR® 2!

The front shroud panel comes in seven colors. Order the **TRUE BLUE** or **CANDY APPLE RED** models and receive the matching insert. Order the **MATTE BLACK** model (standard) and you may choose any other color insert. Plus, purchase any additional colors as an accessory!



20" x 18" limited recline memory foam seat with manual adjustment and height/width/depth/angle adjustable armrests and sliders

Two rearview mirrors

Front LED lighting includes headlights and directional signals

Front storage compartment on tiller

Tubeless pneumatic tires for a smooth and stable ride

Rear brake lights increase visibility for additional safety

Non-Medical Device**

Enjoy fast speed and advanced safety features, all in one sleek package! The Baja™ Raptor 2 cruises up to 14 mph and is equipped with a full LED lighting package and a regenerative braking system.

Features

- Adjustable thumb throttle
- Hand brake with regenerative braking system
- 60" turning radius
- 19 miles per charge at 400 lbs. (31 miles at 220 lbs.)
- Full LED light package includes LED headlights, directional signals and brake lights that offer full visibility for increased safety
- Easy-to-read LCD console shows fast/slow speed mode, estimated speed, mileage and battery display
- Secure, lockable under seat storage compartment with seat support rod
- Sleek and solid design for enhanced stability
- Front and rear suspension
- Front storage compartment located on the tiller
- Tubeless pneumatic tires for a smooth ride
- XLR USB charger

Available colors

True Blue

Candy Apple Red

Matte Black (Choose a front panel shroud)

Accessories*

- 50-90" lap belt
- Cane/crutch holder (single, double)
- Cell phone holder
- Cup holder
- Forearm crutch holder
- Oxygen tank holder
- Quad cane holder
- Rear basket
- Saddle bag
- Safety flag
- Walker holder
- Weather cover
- Wishbone crutch holder
- Additional front panel shroud inserts

Military Patches



*Only one rear accessory can be used at a time.

Hand brake with standard regenerative and electro-mechanical braking system

Easy-to-read LCD console shows fast/slow speed mode, estimated speed, mileage and battery display

Secure, lockable, under-seat storage