

{10.80}



Super Erecta Pro®

Durable and Cleanable. The original — reinnovated.

Corrosion resistant shelving constructed of removable polymer open grid shelf mats over a wire shelf frame. Shelf frames and posts have Metroseal epoxy coating over an electroplated substrate. Shelves with polymer mats offer a 20 year limited warranty against corrosion, while posts offer a 15 year warranty against corrosion. Microban® antimicrobial product protection is built into the frames, shelf mats and posts to help keep product cleaner between cleanings. Shelf has a rigid four-sided frame with center truss(es). Robust corner provides complete 360° capture of the split sleeves and post for added stability. Stationary units have maximum capacity of 2,000 lbs. (907kg) evenly distributed. Mobile units (with stem casters) offer a maximum total unit load of 900 lbs. (408kg). Units assemble easily — shelves mount on split sleeves along grooved, numbered posts and adjust on 1" (25mm) increments.

- **Prolonged durability:** Polymer shelf mats are corrosion proof and impact resistant. They will not chip, rust, or corrode.
- **Easy to clean:** Removable polymer shelf mats can easily be lifted off the shelf frames for cleaning in sinks or wash/dish machines.
- **Strong and robust:** Steel corners, side and center supports assure a sturdy and stable weight bearing surface.
Weight capacities for evenly distributed loads:
800 lbs. (363kg) per shelf for lengths of 24" to 48" (610 to 1220mm)
600 lbs. (275kg) per shelf for lengths of 54" (1370mm) or longer
2,000 lbs. (907kg) maximum per stationary unit.
- **Interchangeable:** Super Erecta Pro shelves are compatible on the same shelving units with other Super Erecta shelving options: Super Erecta wire, Super Adjustable Super Erecta, Solid Super Erecta shelves, Dunnage shelves, Cantilever shelves. Super Erecta Pro shelves can be used with Post-Type Wall Mounts, Direct Wall Mounts, SmartWall Wall Mounts, Security Units, Top Track, and qwikTRAK systems.
- **Microban® Product Protection:** Microban® antimicrobial product protection is built into the shelf mats and the Metroseal Green epoxy coating protects the product from bacteria that cause odors and product degradation. Microban protection keeps the product "cleaner between cleanings".
- **Efficient use of storage space:** Shelves can be adjusted at 1" (25mm) increments along the post to maximize the use of available vertical storage space.
- **Open Grid Shelf Mats:** Open grid shelves promote air circulation and light penetration.
- **Fast, Easy Assembly:** Super Erecta Pro units assemble easily in minutes, without tools. SiteSelect posts have numbered grooves and feature unique double grooves every 8" (203mm) to help position the shelves.
- **Warranty against rust and corrosion:** Shelves with polymer shelf mats – 20 years. Posts – 15 years. Shelf mats are constructed of polypropylene and will never rust.



For stem casters,
see catalog sheet #11.20



MICROBAN® and the MICROBAN® symbol are registered trademarks of the Microban® Products Company, Huntersville, NC. Microban® product protection does not by itself protect a user from food borne illness. Product must be routinely cleaned.

Supports good
HACCP
processes




All Metro Catalog Sheets are available on our website: metro.com

Super Erecta Pro®

Standard Shelves

- Part number includes shelf with removable polymer shelf mats and one bag of split sleeves

Nominal Width/Length (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)	Model No. SE Pro Metroseal Green
14x24 355x610	4.5 2.0	PR1424NK3
14x30 355x760	6.3 2.9	PR1430NK3
14x36 355x914	8.0 3.6	PR1436NK3
14x42 355x1060	10.0 4.5	PR1442NK3
14x48 355x1219	11.9 5.4	PR1448NK3
14x60 355x1524	14.9 6.8	PR1460NK3
14x72 355x1829	18.3 8.3	PR1472NK3
18x24 457x610	6.0 2.7	PR1824NK3
18x30 457x760	7.8 3.5	PR1830NK3
18x36 457x914	9.5 4.2	PR1836NK3
18x42 457x1060	11.3 5.0	PR1842NK3
18x48 457x1219	13.0 5.8	PR1848NK3
18x54 457x1372	14.8 6.6	PR1854NK3
18x60 457x1524	16.5 7.4	PR1860NK3
18x72 457x1829	19.8 8.8	PR1872NK3
21x24 530x610	8.0 3.6	PR2124NK3
21x30 530x760	9.5 4.2	PR2130NK3
21x36 530x914	11.3 5.0	PR2136NK3
21x42 530x1060	12.5 5.6	PR2142NK3
21x48 530x1219	14.3 6.4	PR2148NK3
21x54 530x1372	16.5 7.4	PR2154NK3
21x60 530x1524	18.3 8.1	PR2160NK3
21x72 530x1829	21.5 9.6	PR2172NK3
24x24 610x610	9.5 4.2	PR2424NK3
24x30 610x760	11.3 5.0	PR2430NK3
24x36 610x914	13.0 5.8	PR2436NK3
24x42 610x1060	14.0 6.3	PR2442NK3
24x48 610x1219	15.5 6.9	PR2448NK3
24x54 610x1372	18.3 8.1	PR2454NK3
24x60 610x1524	20.0 8.9	PR2460NK3
24x72 610x1829	23.3 10.4	PR2472NK3



Actual Dimensions: Width: Add 1/4" (6mm) to nominal size. Length: Subtract 1/4" (6mm) from nominal size.

Note: Polymer Shelf mats are designed to fit Super Erecta Pro shelves and cannot be retrofitted to Super Erecta wire shelves.

Replacement Split Sleeves

Model No. 9985 (Bag of four sets.)

Specifications

- Shelf frames:** Carbon steel with Metroseal Green epoxy coating.
- Polymer Shelf mats:** polypropylene.
- Microban® antimicrobial product protection** is built into the polymer shelf mats and Metroseal Green epoxy coating.
- NSF listed for all environments.**
- Continuous Temperature:** Super Erecta Pro Shelves can be used continuously within a range of -20/120° F (-29/49° C). For cleaning only, the unloaded product or shelf mats may be intermittently exposed to temperatures up to 200° F (93° C).

NOTE: Not suitable for cart wash applications.

SHELVING HEIGHT GUIDELINES

Shelf Depth	14" (356mm)	18" (457mm)	21" (533mm)	24" (610mm)
Maximum Post Height Allowable				
Stationary	63" (1600mm)	86" (2184mm)	86" (2184mm)	96" (2438mm)
Mobile	54" (1372mm)	74" (1880mm)	74" (1880mm)	86" (2184mm)

Note: For stationary units with foot plates or wall brackets properly attached to the floor or wall, the maximum allowable height is 96" (2438mm).

SiteSelect Posts

Stationary post height includes leveling bolt.

STATIONARY

Actual Height (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)	Model No. Metroseal Green	Model No. Stainless
14 1/2 370	1.0 0.5	13PK3	13PS
34 1/2 875	2.0 0.9	33PK3	33PS
54 9/16 1385	3.0 1.4	54PK3	54PS
62 9/16 1590	3.5 1.6	63PK3	63PS
—	—	—	—
74 5/8 1895	4.0 1.8	74PK3	74PS
86 5/8 2200	5.0 2.3	86PK3	86PS

MOBILE (For use with stem casters)

Actual Height (in.) (mm)	Approx. Pkd. Wt. (lbs.) (kg)	Model No. Metroseal Green	Model No. Stainless
13 3/4 349	1.0 0.5	13UPK3	13UPS
33 3/4 857	2.0 0.9	33UPK3	33UPS
53 13/16 1366	3.0 1.4	54UPK3	54UPS
61 13/16 1570	3.5 1.6	63UPK3	63UPS
69 3/4 1772	3.8 1.7	70UPK3	—
73 7/8 1876	4.0 1.8	74UPK3	74UPS
85 7/8 2181	5.0 2.3	86UPK3	86UPS

NOTE: Special length posts are available. Consult your Metro representative.

"S" Hook: Used to "add on" one or multiple Super Erecta Pro shelving units while eliminating the cost of two posts per unit. Can be used to join units end-to-end, back-to-back, at right angles, etc. Two "S" hooks are required for each shelf.

Model No. Q9995Z

Notes about "add-on" units.

- Add-on (Adjacent) units must be configured entirely of one style of shelf. (Example: Adjacent unit may be configured entirely of Super Erecta Pro OR entirely of Super Erecta Wire/Super Adjustable shelves.)
- To connect an adjacent Super Erecta or Super Adjustable Super Erecta wire shelving unit to a Super Erecta Pro unit using S-hooks, the adjacent unit must use S-hook model number Q9995Z.
- A mixed shelving unit having a combination of Super Erecta Pro, Super Erecta wire, and Super Adjustable cannot be connected to another unit with "S" Hooks.

